
BKO - BRACKETS FOR **FO** MANUAL CONTROL

CODE **560900**




Allow to connect the **FO** remote control levers.

561144 - STAFFE BKO/1
561145 - STAFFE BKO/2
561146 - STAFFE BKO/3
561147 - STAFFE BKO/4
561148 - STAFFE BKO/5
561149 - STAFFE BKO/6
561150 - STAFFE BKO/7
561151 - STAFFE BKO/8

BKA - BRACKETS FOR **FA** MANUAL CONTROL

CODE **561153**





Used to put together **FO** and **FA** remote control levers.

561152 - BRACKET BKA/1
561153 - BRACKET BKA/2
561154 - BRACKET BKA/3
561143 - BRACKET BKA/4
561155 - BRACKET BKA/5
561156 - BRACKET BKA/6
561157 - BRACKET BKA/7
561158 - BRACKET BKA/8

FL - CABLE ADAPTER

CODE **801330**







Allows the assembly of flexible cables on the valve (lever side).

SPOOL CONTROL **1F**

CODE **802132**






Allows the spool to move in position 1 and 2 by pushing and pulling the lever: spool goes back to position 0 when the handle is released (spring return). Integrates the connection kit to flexible cable remote control (spool control side).

CA - CABLES FOR REMOTE CONTROL

CODES



023038 - LENGTH = 0,5 m
023087 - LENGTH = 1,0 m
023088 - LENGTH = 1,5 m
023089 - LENGTH = 2,0 m
023090 - LENGTH = 2,5 m
023091 - LENGTH = 3,0 m
023092 - LENGTH = 3,5 m
023093 - LENGTH = 4,0 m