SPARE PARTS

DO - CAM

Code 801044






Cam actuator.

HO - HYDRAULIC

Code 801246 - Single
Code 561068 - Double







Hydraulic actuator for remote control.

MX - SAFETY LEVER

Code 801262






The lever can be actuated only after the mechanical security system is released. It can be combined with other actuators in other sections.

MR - MANUAL ROTARY LEVER (BM70 / BM100 ROTATIVO)

Code 801301






It allows the spool positioning in all the positions within the minimum and the maximum stroke. The lever has to be rotated around the spool axis. See page 31 for the spool control features (8DN).

JS1 - MEHCANICAL JOYSTICK

Code JS1 - 801291








Operates two spools with one lever handle. Two spools can be operated indipendently or simultaneously, depending on the movement of the handle. Joystick requires to be assembled with spools AS, BS, DS.

JS2 - MEHCANICAL JOYSTICK

Code JS2 - 801292







Operates two spools with one lever handle. Two spools can be operated indipendently or simultaneously, depending on the movement of the handle. Joystick requires to be assembled with spools AS, BS, DS.