

Actuators





The actuator orientation is "**A**" if not differently requested

MO - MANUAL LEVER CONTROL

Code 801014



Standard manual control with lever. Possibility to assembly the lever in vertical or horizontal position.
Possibility to assembly the entire manual control in position A(90°) or B(180°).

MW - MANUAL WOTHOUT LEVER

Code 801116



Manual control as 801014 but the lever is not included.

MC - MANUAL WITH CAM

Code 801010



Manual control as 801014 with the addition of a cam.